KKT 28+ User Manual

1 Welcome

Thank you for purchasing Lava KKT 28+. Your KKT 28+ is packaged with the following state of the art features:

- 1.3 MP Camera
- 2.8Inch screen
- Audio Player
- FM Radio and wireless FM
- Video and FM Recording
- Dual SIM (GSM + GSM)
- T-Flash Card support (up to 16GB)
- Hindi and Punjabi Language Support

Important:

1. Please read the contents of this manual to fully utilize the features of this phone.
2. Please read the Guidelines section provided with this Reference guide.

Table of Contents

1 Welcome 2
2 Know Your Phone 5
2.1 Keys and Parts 5
2.2 Insert SIM Card 5
2.3 Insert Memory Card 5
3 Basic Operations 6
3.1 Switch Phone ON/OFF 6
3.2 Unlock the phone 6
3.3 Make a call 6
3.4 Receive/Reject a call 6
4 Notable Features 6
4.1 Secure your Phone 6
5 Contacts 6
5.1 Add New Contact 6
5.2 Send SMS 7
5.3 Call a Contact 7
5.4 Delete a Contact 7
5.5 Delete multiple contacts 7
5.6 Import/Export Contacts 7
5.7 Send vCard 7
5.8 Others 7
5.9 Groups 7
6 Call logs 8
6.1 View Call logs 8
7 Settings 8
7.1 Call settings 8
7.2 Phone settings 8
7.3 Display settings 8
7.4 Security settings 8
7.5 Profiles 8
7.6 Connections 8
7.7 Dual SIM settings 9
7.8 Restore factory setting 9
8 My files 9

9 Messages 9
9.1 Write message 9
9.2 Use message Templates 9
9.3 Broadcast message 9
9.4 Settings 9
9.5 Message capacity 9
10 Multimedia 9
10.1 Image viewer 9
10.2 Video Recorder 10
10.3 Video Player 10
10.4 FM Radio 10
10.5 Sound Recorder 10
11 Camera 10
12 Music 10
13 Organizer 11
13.1 Calendar 11
13.2 Alarm 11
14 Tools 11
14.1 Bluetooth 11
14.2 Calculator 11
14.3 World clock 11
14.4 Torch 11
15 Fun & Games 11
15.1 Lava Zone 11
15.2 Kandy Crash 11
15.3 Snake 11
16 Internet 12
17 Health and Safety Precautions 12
18 Taking Care of Your Device 13
19 LAVA WARRANTY CERTIFICATE 15

2 Know Your Phone

2.1 Keys and Parts

Important keys and parts are listed here for you to use the phone better.

2.2 Insert SIM Card

The KKT 28+ is a Dual SIM mobile phone allowing you to use two SIM Cards.

1. Switch off the mobile phone and remove the rear cover and battery.
2. Insert the SIM card correctly in the SIM slot(s).
3. Finally, insert the battery and place the rear cover of the mobile phone.

2.3 Insert Memory Card

1. Switch off the phone and remove the rear cover and the battery.
2. Insert the memory card into the slot.
3. Finally, insert the battery and the rear cover of the mobile phone.

Note: Use only compatible memory cards approved for KKT 28+. Incompatible cards may damage the slot or corrupt the data stored in the card.

3 Basic Operations

3.1 Switch Phone ON/OFF

To switch ON/OFF your phone, press and hold the **End key** for a few seconds.

3.2 Unlock the phone

If you do not use the phone for a while, the screen is replaced with a locked screen.

1. Press any key to activate the screen.
2. Press **Left** key, and then press * key.

3.3 Make a call

You can make a call in the following ways:

- Enter the desired number in standby mode and press the **Call key** to make the call.
- Go to **Menu >Contacts** and then select and dial the desired number.
- Just press the **Call key** to dial the contacts listed in Call logs.
- You can also dial a contact from the messages.

3.4 Receive/Reject a call

- When there is an incoming call,you can press **Left key** or press the **Dial call key** to receive
- If you do not want to receive the incoming call,you can press the **End key** to reject

4 Notable Features

4.1 Secure your Phone

Menu > Settings > Security settings > Phone lock

Let you lock/unlock your phone via a security password which you can change anytime.

The default security code to unlock the phone is **4321**.

Note: After you activate the phone lock, you would be asked for a password when you power on your phone next time.

5 Contacts

Your phonebook stores all your saved contacts for anytime use. Your phonebook data can be stored in your SIM card or your phone memory. You can manage your contacts from here.

Menu > Contacts

5.1 Add New Contact

Menu > Contacts > Left Key >New

5.2 Send SMS

Menu > Contacts > Left Key > Write message

5.3 Call a Contact

Menu >Contacts > Left Key > Call>Voice call

Allow you to make a call to the contact you are viewing. Or you can just highlight a number and press the **Call** key.

5.4 Delete a Contact

Menu > Contacts > Left Key> Delete

In the Contacts list, select the entry you want to delete.

5.5 Delete multiple contacts

Menu > Contacts > Left Key> Delete multiple

In the Contacts list, select the entry you want to delete.

5.6 Import/Export Contacts

Menu > Contacts > Left Key > Import/Export

You can copy, Import or Export contacts entries stored in the SIM card to the phone memory and vice-versa.

5.7 Send vCard

Menu > Contacts > Left Key > Send vCard

Allow you to send vCard to other numbers and export vCard.

5.8 Others

Speed dial

Menu > Contacts > Left Key >Others> Speed dial

You can set speed dial from the Contacts or edit new number.

Memory status

Menu > Contacts > Left Key >Others>Memory status

Check the memory status of SIM, and Phone.

5.9 Groups

Menu>Contacts > Groups

Press the Right navigation key to access the Group tab. You can build new group or mass texting.

6 Call logs

6.1 View Call logs

Menu > Call logs

Tip: Directly access the call logs of by pressing the **Call** key in idle mode.

The Call log lists the calls you have recently dialed, received, missed for SIM1 and SIM 2.

Press the Left/right navigation keys to access various call logs and work on the call logs.

7 Settings

Choose various preferences to customize your handset according to your requirements. You can set:

7.1 Call settings

Menu > Settings>Call settings

To perform the call divert, call waiting, call barring, Fixed dialing, Others.

7.2 Phone settings

Menu > Settings>Phone settings

To perform the Date & time, Language settings, Preferred input method, Dedicated keys, Schedule power on/off, Battery Status and, Shortcuts.

7.3 Display settings

Menu > Settings>Display settings

Performance related Settings shown as wall paper, and standby interface, backlight and the backlight time, key backlight time setting

7.4 Security settings

Menu > Settings>Security settings

Execute related the SIM1/2 security, mobile security, automatic keyboard lock, and end keys locked fast, anti-theft tracking and privacy protection.

7.5 Profiles

Menu > Settings>Profiles

Activation and customize the required profile is General, Silent,
Meeting, Indoor, Outdoor, Headphones, Bluetooth.

7.6 Connections

Menu > Settings>Connections

You can set connectivity including Data account.

7.7 Dual SIM settings

Menu>Settings>Dual SIM settings

To perform Standy mode,reply by master by master SIM,Set SIM name.

7.8 Restore factory setting

Menu>Settings> Restore factory setting

Input correct password,then you restore settings and restar the phone

8 My files

Menu > My files

You can check memory card files from my files.

9 Messages

9.1 Write message

Menu > Messages > Write message > New SMS

You can compose and send SMS. Pressing the **Left Key** during/after composing the message gives you a host of messaging features.

9.2 Use message Templates

Menu > Messages >Templates

Enter into preset message templates and use them. These preset templates can save you time if the theme of your message is the same as those existing in the template.

9.3 Broadcast message

Menu > Messages >Broadcast message

To receive public messages on all different subjects from your network operator

9.4 Settings

Menu > Messages > Options>Settings

You can set your desired parameters for SMS and Others.

9.5 Message capacity

Menu > Messages >Options> Message capacity

View the memory status of your SMS.

10 Multimedia

10.1 Image viewer

You can manage the images which saved in phone memory or TF-card.

10.2 Video Recorder

Menu >Multimedia>Video Recorder

Press the **OK** Key to start recording.

- You can press Options switch to **Camera** and vice versa.
- You can also press **Options** key to choose memory
- Press **Left key** to choose various settings

10.3 Video Player

Menu >Multimedia> Video Player

Let you play videos stored in your phone or memory card.

Press * key while playing a video to change the display mode.

Press 4/6 key while playing a video to decrease or increase the brightness.

10.4 FM Radio

Menu >Multimedia> FM radio

Your phone is with wireless FM radio to let you listen to FM channels.

- Go to Options> Search Channels> Auto Search to fill up the channels.
- Press the number keys on your keypad in accordance to the channel list.
- Press OK key to start/stop the radio.
- Press the navigation-Up or Down key to increase/decrease the volume.
- Press the Left key for various radio options.

10.5 Sound Recorder

Menu >Multimedia> Sound Recorder

You can record surrounding sounds using this feature.

11 Camera

Press the navigation up key in camera mode and press LSK to choose the difference functions.

12 Music

The phone comes with an inbuilt audio player that plays all your favorite songs stored in the phone memory or memory card.

- While in music mode, press the Left key to choose various music options
- **Adjust Volume:** Press Up and Down keys to adjust volume.
- Press CSK to Start or pause.

13 Organizer

13.1 Calendar

Menu >Organizer> Calendar

You can check the date and can reminder you after setting an event.

13.2 Alarm

Menu >Organizer>Alarm

To use the alarm service available with your mobile phone.

14 Tools

14.1 Bluetooth

Menu >Tools> Bluetooth

Open the Bluetooth, for file transfer and acceptance

14.2 Calculator

Menu >Tools> Calculator

To provide a calculator with 4 basic functions to facilitate simple calculations.

14.3 World clock

Menu >Tools> World clock

Press the Left key for various options.

14.4 Torch

Menu >Tools> Torch

You can turn on/off Torch

15 Fun & Games

15.1 Lava Zone

Menu >Fun & Games>Lava Zone

We can use this to download MP3, Video, Wallpaper and other content.

15.2 Kandy Crash

Menu > Fun & Games > Kandy Crash

We can Play the Kandy Crash game 3 free trials.

15.3 Snake

Menu > Fun & Games >Snake

We can Play this game free.

16 Internet

Menu >Internet

To access this menu, enter the Main Menu in the standby mode and then select Internet. You can use the network-related services with this function.

17 Health and Safety Precautions

Please read these simple guidelines. Not following them may be dangerous or illegal.

SAR Compliance

- Your phone is designed not to exceed the limits of emission of radio waves recommended by international guidelines.
- SAR (specific absorption rate) is the measurement of body-absorbed RF quantity when the phone is in use. SAR value is ascertained according to the highest RF level generated during laboratory tests.
- The SAR value of the phone may depend on factors such as proximity to the network tower, use of accessories or other accessories.
- The highest SAR value of the device at the head and body are below 1.6W/kg respectively averaged over 1 gm. of human tissue.

SAR Recommendations

- Use a wireless hands-free system (headphone, headset) with a low power Bluetooth emitter.
- Please keep your calls short and use SMS whenever more convenient. This advice applies especially to children, adolescents and pregnant women
- Prefer to use your cell phone when the signal quality is good.
- People having active medical implants should preferably keep the cell phone at least 15 cm away from the implant.
- Maintain a preferable distance of 15 mm from the device.

Safe Driving

- Do not use the phone while driving. When you have to use the phone, please use the personal hands-free kit.
- Please do not put the phone onto any passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.

During Flight

- Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone during a flight.

In Hospitals

- Your Phone's radio waves may interfere with the functioning of inadequately shielded medical devices. Consult a physician or the manufacturer of the medical device to determine whether they are adequately shielded from external Radio Frequency. Switch off your device when regulations posted instruct you to do so.
- To avoid potential interference with implanted medical devices such as a pacemaker or cardioverter defibrillator:
- Always keep your phone at least 15.3 centimeters (6 inches) from the medical device.
- Do not carry the wireless device in chest pocket.
- Turn off the phone if there is any reason to suspect that interference is taking place.
- Follow the manufacturer directions for the implanted medical device.
- If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

Unsafe Areas

- Please turn off your phone when you are close to a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.

18 Taking Care of Your Device

Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery without turning on the device, wipe it with a dry cloth and take it the service center.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not attempt to open the device other than as instructed in this guide. Repairing this phone by yourself other than our authorized service agents/centers goes against the warranty rules.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not store your device near magnetic fields or allow your device to come in contact with magnetic fields for extended period of time.

Battery Recommendations:

- Please put the battery in a cool and well-ventilated place out of direct sunlight. We recommend you to charge the battery at room temperature range.
- Batteries have life cycles. If the time that the battery powers equipment becomes much shorter than usual, the battery life is at an end. Replace the battery with a new battery of the same make and specification.
- Do not discard the battery with household trash. Please dispose of used battery according to your local environmental laws and guidelines.
- Use manufacturer approved batteries, chargers, accessories and supplies. KKT 28+ will not be held responsible for user's safety when using unapproved accessories or supplies.

Recycle Your Handset

The WEEE logo (shown at the left) appears on the product (battery, handset, and charger) to indicate that this product must not be disposed of or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste.

Specified collection points for recycling of such hazardous waste. Collection and proper recovery of your electronic waste equipment at the time of disposal will allow us to help preserve the environment. Recycling of the electronic waste equipment will ensure safety of human health and environment. For more information on best practices for disposal of electronic and electrical waste, please visit to our web site: www.Lavamobiles.com

Disclaimers

1. The colors and specifications shown/mentioned in the user manual may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.
2. KKT 28+ keeps the right to make modifications to any of the content in this user guide without public announcement in advance. The content of this manual may vary from the actual content displayed in the mobile phone. In such a case, the latter shall govern.

Copyrights

All rights reserved. Reproduction, transfer, distribution or storage of part of all of the contents in this document in any form without the prior written permission of Lava International is strictly prohibited.

19 LAVA WARRANTY CERTIFICATE

Limited warranty:

LAVA international Ltd. (LAVA) provides limited warranty for your mobile phone and original accessories delivered with your mobile phone (hereinafter referred to as "product")

The warranty period for the transceiver is one (1) year and for battery, charger and headset is six (6) months from the date of purchase.

LAVA Warranty

Subject to the conditions of this Limited Warranty, LAVA warrants a product to be free from defects in design, material and workmanship at the time of its original purchase by you, and for a subsequent period of one (1) year for transceiver and six (6) months for battery & charger.

You shall have to coverage or benefits under this warranty in the event that any of the following conditions are applicable:

1. The product has been subjected to abnormal use or conditions, improper storage, exposure to excessive moisture or dampness, exposure to excessive temperature, unauthorized modification, unauthorized repair (including but not limited to use of unauthorized spare parts in repairs),abuse, accidents, Acts of God, spills of food or liquids, improper installation.
2. You have not notified Lava of the defect in the product during the applicable warranty

period.

3. The product serial no. code or the accessories date code has been removed, defaced or altered.
4. The product has been used with or connected to an accessory (i) Not supplied by Lava or its affiliates, (ii) Not fit for use with the product or (iii) Used otherwise than in manner intended.
5. The seals of the product's battery enclosure have been broken or shown evidence of tempering or the product's battery has been used in equipment other than that for which it has been specified usable by LAVA.
6. All plastic surfaces and all other externally exposed part that is scratched or damaged due to normal use.

To get maximum of your new product, we recommend you to:

- Read the guidelines for safe and efficient use as mentioned in the manual.
- Read the terms and conditions of your Lava warranty in the manual.
- Keep your original receipt; you will need it for warranty services if asked to produce.
- Present this Lava Warranty Certificate along with original proof of purchase whenever you require any warranty services.

In case Lava product needs service, please visit the nearest Lava service centers given in the service guide. Please visit our Website www.lavamobiles.comfor updated list of Authorized Service Centers near to your location.

Important note: for your warranty to be valid, all information on the warranty certificate has to be completed including the stamp from the authorized distributor/retailer.

All warranty information, product features and specifications are subject to change without notice.

IMEI No. .....

Dealers Stamp .....

Date of purchase .....

Model No. .....